




User Manual

# **MYNT MYHYGGE VACUUM MUG**



MN-PU02.

Please read and keep this manual carefully before using the product.

## PRODUCT DESCRIPTION

Part Name	Material
Inner Layer	Ceramic Coated
Outer Layer	Stainless Steel, SS304
Plastic Parts / Top Lid	Polypropylene (PP)
Rubber Parts	Silicone Rubber

## INSTRUCTIONS FOR USE:

1. Please clean the cup or pot body and various parts with neutral detergent before use.
2. Add a small amount of water for preheating/precooling to enhance better thermal/cold insulation effects.
3. After use, tighten the cup lid clockwise to prevent leakage.

## NOTES

1. It is not suitable for keeping dairy products or baby food warm for extended periods. Dairy products should not be stored for more than 2 hours to avoid the risk of bacterial growth.
2. Avoid storing acidic drinks such as plum juice and lemon juice, as they may compromise the heat preservation capabilities.

3. Do not store carbonated drinks or dry ice to avoid dangers such as internal pressure rising, causing the cup lid to fail to open or the contents to erupt.
4. Do not use heating equipment such as microwave ovens to heat the product.
5. Do not use dishwasher. Do not use it for purposes other than keeping warm/cold.
6. When filling hot water, please keep the product out of the reach of small children and drink with caution to avoid burns.
7. Do not place the product near high temperatures, as it may cause deformation, discoloration, or paint peeling.
8. Please pay attention to control the amount of water added, maintain it 2-3cm below the mouth of the cup or the water seal mark. Tighten the cup lid to avoid overflow and burns.
9. Do not use abrasive powder, metal cleaning balls, oil removers or chlorine-containing cleaners to avoid scratches, rust or corrosion on the product surface.
10. Please avoid dropping the product or subjecting it to significant impacts to avoid affecting the thermal insulation performance.
11. If you put salty food or soup in, please take it out within 12 hours and clean the inside and outside of the product.

## HOW TO CLEAN

1. Please use a soft cloth or a damp sponge dipped in neutral detergent to wipe the surface of the product.
2. The product must be thoroughly cleaned before and after each use.

## MAINTENANCE METHOD

1. When not in use for an extended period, please wipe the product inside and outside, ensuring it is completely dry.
2. When cleaning, please avoid using alkaline bleach, metal agents, chemical rags, gasoline, metal steel wool, and other cleaning products.
3. Warranty period: The product itself is guaranteed for one year from the date of purchase under normal use. However, if the damage is caused by human error or force majeure such as natural disasters or earthquakes, it is not covered by the guarantee.

*\*\* Plastic and silicone accessories are consumables parts. Under normal use, they need to be inspected about every year. If there is any surface damage or unevenness, it is considered normal wear and tear. Please purchase new accessories in time to replace them.*